

# RECOMMENDED CLEANING PROCEDURE

FOR DUROPLAN A SURFACES AND METAL CEILINGS WITH STAINLESS STEEL



	<b>Recommendation</b>	<b>to be avoided</b>
<b>Surfaces with protective foil</b>	<ul style="list-style-type: none"> <li>• store cool, dry and protected from light</li> </ul>	<ul style="list-style-type: none"> <li>• do not store longer than 1 month</li> </ul>
<b>Loose dirt</b>	<ul style="list-style-type: none"> <li>• remove with soft cloth or pressurized air</li> </ul>	<ul style="list-style-type: none"> <li>• avoid rubbing with pressure</li> <li>• avoid use of paper towels or similar</li> </ul>
<b>General</b>	<ul style="list-style-type: none"> <li>• use clean cotton gloves when handling parts</li> <li>• use only clean, new lint-free cotton or micro-fibre cloths</li> <li>• first cleaning attempt on non-visible spot</li> </ul>	<ul style="list-style-type: none"> <li>• avoid use of excessive force</li> <li>• do not touch surface with bare fingers (danger of fingerprints)</li> <li>• avoid repeated use of soiled cloths</li> </ul>
<b>Light contamination</b>	<ul style="list-style-type: none"> <li>• use dilute lemon-based household cleaning agent</li> <li>• adhere to recommendations for dilution of cleaning agent manufacturer to ensure a pH-value between 3.0 and 4,5</li> </ul>	<ul style="list-style-type: none"> <li>• do not use undiluted cleaner</li> <li>• do not use vinegar-based cleaners</li> <li>• neutral or alkaline agents are unsuitable</li> </ul>
<b>Heavy contamination</b>	<ul style="list-style-type: none"> <li>• greasy or oily contaminations can be removed with a mixture of alcohol and water (1:1)</li> <li>• residues of alcohol-based cleaners can be removed with a moist cotton cloth</li> <li>• persistent contaminants may be softened with dilute lemon-based cleaning agent</li> </ul>	<ul style="list-style-type: none"> <li>• do not scrub with hard tools</li> <li>• do not use concentrated acids or alkalis</li> <li>• do not use cleaning benzine or spirit</li> <li>• unsuitable cleaning agents such as oven-spray, window-cleaner, drain-cleaner, wheel rim cleaner, lime scaler remover, and such like are to be avoided</li> <li>• do not use ultrasonic cleaning</li> </ul>
<b>General cleaning agents</b>	Industrial cleaning agents e.g. Würth Art. Nr.: 0782140	
<b>Cleaning and protection agents for aluminium surfaces</b>	e.g. Frosch® Zitronenreiniger e.g. Würth Reiniger Typ 60 Art. Nr.: 0892130030	
<b>Cleaning and protection agents for stainless steel surfaces</b>	basic cleaning agents <5% nonionic surfactants and >30% aliphatic hydrocarbons e.g. Würth Edelstahlkraftreiniger Art. Nr.: 08931212	
<b>Care and maintenance products</b>	e.g. Dr. Beckmann Art. Nr.: 4008455037319	